

# Laundry 101

## Quick & Easy Steps

1. Place dirty clothes in washer.
2. Select cycle.

Type of Fabric	Cycle	Water Temp
Whites	Regular	Hot
Colors	Regular	Warm/Cold
Perm Press	Perm Press	Cold
Delicates	Delicates	Cold
Wool	Delicates	Cold

3. Add 1 tablespoon (equivalent to 1 coffee creamer) of regular detergent or the amount recommended on bottle if using High Efficiency.
4. If using bleach or fabric softener add that now, too.
5. Did you forget to add any clothes? If not, shut the door. Remember it locks.

## **BASC** connects you to sustainability.

The new high efficiency front loading washers require less water, hold larger loads and save energy in reduced water heating. They also extract more water from your clothes, shortening drying time and saving even more energy.